

3800 Scanner commands

To program the scanner for automatic trigger operation:

1. Print this web page.
2. Open Notepad, Wordpad, SimpleText or other word processing program.
3. Scan the "Auto Trigger" barcode below for hands-free scanning when using a stand.

Auto Trigger



To program the scanner for manual trigger operation (default):

1. Print this web page.
2. Open Notepad, Wordpad, SimpleText or other word processing program.
3. Scan the "Manual Trigger" barcode below.

Manual Trigger



To adjust the volume of the ImageTeam 3800 scanner:

1. Print this web page.
2. Open Wordpad, Notepad, Simple Text, or other text-editing program.
3. Scan one of the four barcodes below that reflects the desired volume level. The default setting is "High."


High



Medium



Low



Off

